

Protoseal® Instructions

Protoseal® for Waterproofing

Step 1 – Clean debris, dirt, etc from coating area.

Step 2 – Pour **Protoseal** into a hand pump sprayer with wand.

Step 3 – Apply **Protoseal** to necessary areas, fully saturate the areas however, do not puddle.

Step 4 – Wait until dry, approx 24 hours and then clean the surfaces with **ArmorGuard** Cleaner.

Protoseal for Stain Lifting

Step 1 – Clean debris, dirt, etc from coating area and scarify concrete by sandblasting or grinding. The goal is to open the pores of the concrete to allow better absorption for **Protoseal**.

Step 2 – Pour **Protoseal** into a hand pump sprayer with wand.

Step 3 – Apply **Protoseal** to stained areas, fully saturate the areas however, do not puddle.

Step 4 – Wait approx 24-48 hours or until you notice the stains stop expanding in size. When complete, clean the surfaces with **ArmorGuard** Cleaner.

Protoseal for “Green” Concrete

Protoseal will help accelerate the cure time of New Concrete by approx 50%; concrete under normal conditions fully cures in about 28 days according to the American Concrete Institute

Step 1 – Clean debris, dirt, etc from coating area.

Step 2 – Pour **Protoseal** into a hand pump sprayer with wand.

Step 3 – Apply **Protoseal** to necessary areas, fully saturate the areas however, do not puddle.

Step 4 – Wait approx 14 days for the concrete to cure, and then clean the surfaces with **ArmorGuard** Cleaner

IMPORTANT NOTE:

- We recommend you perform moisture and vapor tests prior to coating. You will want less than 20% moisture and under 3 lbs of vapor transmission.
- Never Coat a Wet Surface
- **Always follow common safety procedures.**
- Wear rubber gloves
- 1 gallon covers approximately 150-200 square feet.